



USB DVB-T2 Dongle



Specification:

TUNER (DVB-T2)	Frequency Range	48.25~863.25MHz
	Input Level	-90~-20 dBm
	Input Impedance	75Ohm IEC connector
	ANT Loop-Through	51MHz~858MHz full Band loop through
CHANNEL DECODING (DVB-T2)	Standard	DVB-T2[EN302 755]
	Bandwidth	1.7,5,6,7,or8MHz
	FEC	LDPC + BCH 1/2, 3/5, 2/3, 3/4, 4/5, 5/6
	Demodulation	QPSK,16QAM,64QAM,128QAM,256QAM
	Guard Interval	1/4, 19/256, 1/8, 19/128, 1/16, 1/32, 1/128
	FFT size	1k, 2k, 4k, 8k, 16k, 32k
	Scattered Pilots	1%, 2%, 4%, 8% of total
	Continual Pilots	0.35% of total
DECODING	Video format	MPEG-II main Profile & Main Level,H.264
	Audio format	MPEG-II Studio Layer I & II

Feature:

1. USB 2.0 high speed interface
2. Free to air digital terrestrial DVB-T2(ETS 302 755) Receptions (1.7/6/7/8MHz)
3. Watch and record DVB-T2 TV on PC
4. Listen to DVB-T digital radio
5. Automatic channel searching
6. Schedule TV recording and save directly to your PC's HDD
7. Support Teletext, electronic Program Guide
8. Support H.264 / MPEG-2 HDTV formats up to 1080i / 720p
9. Full function remote control
10. Still image snapshots

System Requirements:

- P4 1.7GHz CPU or higher
- 512M RAM or higher
- VGA Card with at least 16M Memory
- One Free USB 2.0 port(not compatible with USB1.1)
- Microsoft XP/Vista/Win7
- Microsoft DirectX 9.0 or higher

Accessories:

- Software disk-----1pcs
- Remote Controller ---1pcs
- User's manual-----1pcs
- USB cable-----1pcs
- Antenna -----1pcs